

Installation instructions: Fully enclosed canopy

1. Attach rafter poles to rings and add front spacer poles at outer eave. Leave outer eave on ground. (See example photo #1)



Example #1

- 2a. If you do not have a zippered bolt rope strip, guide the bolt rope through the "C" channel from the trailer roof. A second person can help unfold and loft the cover from the ground. (See example photo #2)



Example #2

- 2b. If you do have a zippered bolt rope strip, slide it through the "C" channel from the roof. (Example Photo #3) Unfold the body of the canopy on the roof, zip the "body" to the "strip" and unroll it down the rafters. (Example photo #4)



Example #3



Example #4

3. Pull the cover out towards the ends and down towards the outer eave. (See example photo #5)

Unzip and guide roof end boltrope through vertical "C" channel on trailer side.



Example #5

4. - Zip the rafter pockets around the rafters from underneath.
- Zip roof end bolt rope and pole pockets.
- Attach vertical poles and raise outer eave of canopy. Add ground poles at base of vertical poles



Example #6

5. Zip on full height skirts matching lettered dots. When in use zip skirts together. Zip pole pockets around poles. Buckle strap to ground pole. (See example photo #7)



Example #7